



Meraki HW Decontamination



Guidance for **Cleaning & Decontaminating** Cisco Meraki Hardware

Decontamination Guidance

Decontamination Guidance For: MS & MX

- A basic Clorox wipe down is fine
- Alcohol is also OK
- Don't get wet cleaning liquids + chemicals into vents

Decontamination Guidance For: MR & MG

- Cleaning wipes or alcohol will not impair function
- But may wear away the topmost cosmetic plastic layers
- Do it anyway, you won't hurt the function for thousands of wipes (but you might dull them in appearance)
- As an alternate hot soapy water wipe is also OK

Decontamination Guidance For: MV Cameras

- The bubble absolutely should not be cleaned with a chemical wipe or alcohol
- Water and dish soap are the approved solution For example: Joy or Palmolive
- Harsh cleaners will impact the clarity
- A chamois or optical cloth for drying as well
- Don't get cleaning liquids or chemicals inside the camera